

femooi

icee™ Product Manual



Thank you for purchasing the femooi icee™ device.

Please take a few moments to read the instructions in this manual carefully before using this device.

About icee™

icee™ is about to bring you the most enjoyable skin cleansing experience, helping you to rejuvenate your natural, fresh and radiant skin. Below we show you a comprehensive introduction about the unique functions of femooi icee™.



The extremely high-quality silicon material with its skin-friendly and food-grade properties will help you by tending to your delicate skin.



The high-tech silicone material is easy to dry, damp-proof and has anti-bacterial properties. Therefore, it is not necessary to replace the brush which makes this product a sustainable choice, contributing to a better environment.



The delicate and gentle silicone bristles on the brush provide a soft touch. Moreover, the extra-long bristles, combined with the extra-large surface of the brush and the gradually changing angle of the bristles make for the perfect combination of comfort and cleanliness.



The innovative Intellitemp™ technology provides an ice-cold cooling solution to effectively tighten pores, as well as to enhance the smoothness and elasticity of your skin.



Two adjustable cleansing intensities (up to 8000 movements per minute) make it possible to clean deep inside the pores, removing all types of stubborn dirt in the skin such as grease, dead skin and make-up leftovers, meeting a variety of facial cleansing needs.



The unique magnetic charging design makes everyday charging more convenient and easier.




Whether you choose to place the device upright or hang it, the variety of placement methods are practical and interesting.




Originated in the Netherlands, this product is designed with the goal to create a simple, modern, and feminine appearance, bringing an extraordinary and pleasant experience to women.

Device




- ① Deep Cleansing Bristles
- ② Indicator Light
- ③ Ice-cold Cooling Surface
- ④ Operation Interface
- ⑤ Charging Port
- ⑥ Connection for Strap



Hanging Strap



Illustration




Attachment




Usage

Placement




Standing




Hanging

Other Accessories



USB Magnetic Charging Cable







Quick Start Guide
(Printed inside the accessory box)

Using icee™

The unique silicone cleansing bristles of Icee™ can be used with all skin types and provides targeted solutions for different cleansing areas on the face. It is recommended to use Icee™ at least once a day to thoroughly clean your face. The usage frequency of each function can be adjusted depending on your skin condition. Before you start, please study the following important information:

- Charge your Icee™ until the battery is fully charged. Please consult the “Charging” section in this manual for more information.
- Before initial use, unlock the Icee™ by pressing the cooling function button and cleansing function button simultaneously for two seconds.
- icee™ is equipped with a convenient strap that allows you to hang it anywhere, when the strap is not attached, icee™ can stand upright.
- Please test the product first on the back of your hand before using it, to confirm that no abnormalities occur.
- If you notice any redness, swelling, itch or other abnormalities on your skin, discontinue use immediately and consult a physician.
- To protect the health of the skin, we do not recommend sharing your icee™ with anyone else or using icee™ on other areas than the face.

Description of modes

1. Simultaneously press the “Cooling button”  and the “Cleansing button”  for 2 seconds to lock or unlock the icee™. The lock and unlock modes are confirmed through a short vibration and one flash of the indicator light.
2. Press the “Cooling button”  to start the ice-cold cooling mode of icee™. The indicator light will continuously fade from dark to bright to indicate the mode has started. Press the button again to disable the cooling mode.
3. Press the “Cleansing button”  to start the cleansing mode of icee™. The indicator light will flash quickly to indicate the cleansing mode has started. Press the button again within 10 seconds to adjust the cleansing intensity. Two intensity settings are available, the first intensity is meant for gentle skin cleansing, while the second one is for deep skin cleansing. Each time the intensity changes, the indicator light will flash to confirm the choice. After using a setting for more than 10 seconds, the intensity setting will be stored as preferred intensity within the intelligent memory function. When pressing the “Cleansing button” again, the cleansing mode will be disabled. Upon next usage, the cleansing mode will automatically start with the stored preferred intensity setting.

Pay attention:

The standard duration of the ice-cold cooling mode is 1.5 minutes. After the time has passed, the device will vibrate shortly as a reminder and disable the mode automatically. If you would like to continue to use the ice-cold cooling mode, you can enable the mode by pressing the button again.

- * When the icee™ is running low on battery, the ice-cold cooling mode will be automatically disabled. For further details, please consult the “Charging” section in this manual.
- * Please turn off and restart the cleansing mode to reset the preferred intensity setting from the intelligent memory function. This action will restart the 10 seconds intensity adjustment time. During the intensity adjustment time, the “Cleansing button” can be pressed to cycle through the three settings: “gentle skin cleansing” → “deep skin cleansing” → “OFF” .

Detailed Steps

Face cleaning & Care

icee™ Cleansing Mode 





STEP1: Remove make-up from face.



STEP2: Dampen your face and apply your regular cleansing product, make icee™ slightly wet.




STEP3: Press the “Cleansing button”  to start the cleansing mode, and begin to cleanse your face. Press the button again within 10 seconds to adjust the intensity setting of the cleansing mode . For details, please consult the “Description of modes” section in this manual.



STEP4: Every 15 seconds a short pause will remind you to cleanse the next area. It is recommended that you cleanse the following four areas with icee™ sensitive vibration-focus:

1. Left cheek and chin: Clean the cheek and chin using circular strokes;
2. Right cheek and chin: Clean the cheek and chin using circular strokes;
3. Forehead: Use gentle outward strokes starting from the center of the forehead to cleanse the forehead on both sides;
4. Nose: When cleansing your nose, use the deep cleansing bristles and gently wipe the long cleansing brushes up and down on one side, then repeat the cleansing on the other side of the nose;

After 1 minute, the device will notify you that the cleansing routine has been finalized by 3 short pauses in the vibration. Press the “Cleansing button”  to disable the cleansing mode. If you want to continue cleansing, you can continue to use it until the device automatically stops after 2 minutes.




STEP5: After the cleansing process is completed, rinse and dry your face. Then, apply your favorite skincare products.

Pay attention:

- * Please take into consideration your personal skin condition to avoid overuse.
- * Please be careful when cleansing the eye area, prevent direct contact between the device and the eyes or eyelids.
- * It is recommended that people with sensitive skin start using the cleansing function with the gentle cleansing intensity setting, maximum once or twice per week. After the skin becomes accustomed, the deep cleansing intensity can be used according to the skin condition.
- * It is recommended that people with sensitive skin use this product with a gentle motion.

icee™ Ice-cold Cooling Mode



STEP1: Press the “Cooling button”  to start the icee™ ice-cold cooling mode. Gently massage the cold surface of the device over the part of the face with enlarged skin-pores to tighten pores, as well as to enhance the smoothness of your skin.

After 1.5 minutes, the device will notify you that the cooling mode is finished by a small vibration.



Tip: The ice-cold cooling function can also be used on the area under the eyes, to effectively cool down the skin and reduce puffiness around the eyes.


Pay attention:

- * After using the ice-cold cooling mode, please wait for the cooling surface to return to normal temperature before using it for the next time.
- * When the device's temperature is too high, it will automatically enter the protection mode. At this moment, the ice-cold cooling mode cannot be used anymore, and the device will vibrate twice to remind.
- * After using the ice-cold cooling mode, it is normal that the device feels slightly warm. Immediately stop using the ice-cold cooling mode if the device is overheating and extremely hot.


About Power and Charging

Charging

- icee™ comes included with a dedicated USB magnetic charging cable. You can use any qualified USB adapter to charge icee™ with this cable.
- To charge the device, please connect the metal surface of the magnetic head on the end of the USB magnetic charging cable to the device. The cable should be turned to the right-side from the back of the device. When the magnetic head is close to the device, the magnetic head will automatically snap into place. Plug the other end of the USB connector into your own USB power adapter and plug the adapter into the socket.



- When icee™ is in normal charging state, the indicator light of the device will blink in a breathing rhythm. When the charging is finished, the indicator light will change from a breathing rhythm to constantly being on.
- icee™ can be charged in both upright position as well as when hanging down (see the figure below).



- It will take 5 hours to charge icee™ from an empty battery to fully charged.

Pay attention:

- * When the magnetic head is close to the charging port on the back of the device and approached from the right side, the magnetic head will automatically snap into place. When the magnetic head approaches the charging port from the left side, there will be a repulsive force. In this case, do not force the head onto the port, since this might damage the device.
- * When the battery of icee™ is low, the indicator light will flash for 10 seconds to remind you that the cleansing mode is still available, however, the ice-cold cooling mode will not work. The device will give this reminder until the battery's power is completely exhausted.

Warning:

- * Do not immerse the icee™ device into water or other liquids for a long duration.
- * Before charging, make sure that the power cable connector is dry and available. Also confirm that the local power voltage from the outlet matches the indicated required power voltage of the device.
- * Do not charge the device in a location where there is a risk of flooding.

Maintenance

Please take good care of your icee™ for optimum usage and safety.

- Do not use the ice-cold cooling mode continuously and repeatedly, as this might affect the effect of the function.
- After using the ice-cold cooling mode, please wait for the cooling surface to return to normal temperature before using it for the next time. If the temperature of the ice-cold cooling head is too high, icee™ will automatically suspend the function until the temperature returns to normal.
- Please don't hit hard on the ice-cold cooling head to avoid damage.
- The hanging strap is only used for normal hanging usage. Please do not rotate the strap violently and swing the body when the strap is connected to the body to avoid damage.normal.
- After each use, thoroughly clean the device using neutral detergent and clean water. After cleaning, rinse the device with warm water and wipe it dry using a soft cloth or towel.
- Do not use any clay or silicon-based cleanser, or any other granular skincare products such as exfoliating creams or scrubs in combination with icee™. These substances may damage the soft bristles.
- Do not use essential oil based skin care products with icee™, to protect the silicone surface.
- Do not clean the device with alcohol, benzene or acetone-based cleaning products, as these may irritate the skin.
- Do not immerse the body of icee™ in water or other liquids for a long time.
- Do not place icee™ in acidic or alkaline liquids.
- Do not put the icee™ in a dishwasher, microwave oven or high-pressure cooker as this could result in accidents or injuries.
- Avoid direct sunlight and do not expose the device to extreme heat or boiling water.
- Keep the device out of reach from children and do not allow them to use the device.
- Do not use the device when charging.
- Turn off all functions before enabling the self-lock mode.
- Charge your icee™ when the battery is low to extend the battery life.
- Please use the original USB Magnetic Charging Cable included in the icee™ package for charging.
- To avoid damage, do not connect the icee™ USB Magnetic Charging Cable to a low quality power adapter.
- To avoid damage, do not use force to connect the magnetic head (metal contact surface) of the USB Magnetic Charging Cable from the left side to the charging port on the back of icee™.
- Do not disassemble, modify or repair the product.
- Only use the device following the specific instructions mentioned in this manual.



Frequently Asked Questions

The most commonly asked questions about icee™ are listed below. If you are unable to find the answer to your question on this list, please call our customer service hotline for more information.

The light indicator of icee™ does not flash after connecting the magnetic charging cable?

- The battery is completely exhausted and requires to be charged for a few minutes before it shows the light indicator again.
- The magnetic charging cable or power adapted are not connected.

icee™ doesn't respond when the buttons are pressed?

- The self-lock mode is enabled, simultaneously press the "Cooling button"  and the "Cleansing button"  for 2 seconds to unlock the device.
- The internal temperature of the device too high, and the device entered the temperature protection mode. Before trying again, please place the device aside until the temperature dropped back to room temperature.
- The battery is empty, please charge the device.
- The microprocessor encountered a brief operational error. Please connect the charging cable to reset the device to its initial state.

After initiating the ice-cold cooling mode, the temperature of the cooling surface is not getting cooler?

- The battery level is low or exhausted, please charge the battery.
- The microprocessor encountered a brief operational error. Please connect the charging cable to reset the device to its initial state.
- If the outside temperature is extremely hot or cold, it may affect the cooling function of the product. It is recommended to use the device at a suitable temperature (between 5°C and 28°C).

The silicone bristles of icee™ have degraded to a sticky or bubbly texture?

- Discontinue use immediately. Although the silicone of icee™ is highly durable, it may degrade under certain abnormal conditions. Consult this manual's "Maintenance" section on how to avoid this.

Disposal

This device should not be disposed of as household waste. Instead, it should be collected at an appropriate recycling point for electrical and electronic equipment. By ensuring a correct disposal of this device, you will help to contribute to the environment and human health. Further, by recycling this product, you will help with conserving natural resources.

Product Specifications

Product Name: femooi icee™ Facial Cleansing Device

Product Type: FI1.0

Product Materials: Body-safe silicone, ABS and, body safe metal

Product Colors: Flamingo, Iris, Coral, Azure, Sunshine

Device Dimensions: 80 x 54 x 30 mm

Device Weight: 98 g

Rated Power: 110v – 240v

Battery: Lithium-ion battery 1200 mAh, 3.7 V

Charging Time: 2.5 hours

Standby Time: 280 days

Frequency: 100 Hz

Interface: Two function buttons, one indicator light

Disclaimer: Product users at their own risk. Femooi and its distributors assume no responsibility or liability whatsoever for any bodily or non-physical injury or damage that occurs as a direct or indirect result of the use of the product. In addition, Femooi reserves the right to modify this manual and make changes to it at any time and is not obliged to notify any individual of these changes or changes. In case of dispute, the company reserves the right of final decision on the interpretation.

Note: Product or part specifications are subject to change without notice.

©2019 Femooi Technologies, All rights reserved

Femooi (Netherlands): Femooi BV

Address: Kennedyplein 200, 5611 ZT Eindhoven, the Netherlands

femooi (China): Ningbo Femooi Technologies Co., Ltd.

Address: Ningbo Jiangdong Road 375, Feng Ting Building, 8th floor

Customer Service Hotline in Mainland China: 400-800-8681

www.lovefemooi.com